

Sample requirements:

1 liter of solution is need to perform the complete bath analysis.

Sulfamate nickel is not regulated for transportation purposes, but as with all chemicals, simple precautions should be taken. Sample bottles must be shipped in sealed plastic or glass bottles. Sample bottles should be sealed in a plastic bag and packed in a fiberboard box with absorbent material. Print this page and affix the label below to the box.



Send samples to:

DisChem, Inc.
17295 Boot Jack Rd, Suite A
Ridgway, PA 15853 USA

In order to expedite the analysis, please send the purchase order in advance or with the sample.